






Item: 6101-90352-02 /6102-90352-80 5/0 Wood Panel Storage Footboard
 6101-90368-02 /6102-90368-80 6/0-6/6 Wood Panel Storage Footboard
 6101-90353-02 /6102-90353-80 5/0-6/6 Wood Panel Storage Rail


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:








HARDWARE PACK RAIL

NO	DRAWING	DESCRIPTION	SIZE	Q'TY
B		Threaded Rod	Φ5/16"*3-1/2"	8pcs
C		Nut	Ø5/16"*12	8pcs
D		Lock Washer	Φ5/16"×12×1	8pcs
E		Curved Washer	L32*13*8	8pcs
F		Hex Wrench	12MM	1pc

HARDWARE PACK FOOTBOARD

NO	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Screw	8#*1"	28pcs

PART LIST

NO	DRAWING	DESCRIPTION	Q'TY
R		Wood Panel Headboard	1pc
I		Wood Panel Footboard	1pc
H		Rail	2pcs
K		Slats	11pcs
M		Short Support Leg	4pcs
N		Center Slats	1pc
V		Center Slats	1pc

STEP1. Attach Rails (H) to the Headboard Panel + legs (R-M) using Threaded rod (B), Curved washer (E), Nut (C) and tighten them by Open wrench (F)

STEP2. Attach Short support legs (M) to Slats (K)

STEP3. Attach the Slats (K) to the Rails (H) using Screw (A) by the Phillips head screwdriver

