



HOOKER
— FURNITURE —

ASSEMBLY INSTRUCTION


Item: 5323-55584 Entertainment Open Hutch (C)
5323-55484 Entertainment console 84 in

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK



NO	DRAWING	DESCRIPTION		Q'ty
A		SCREW	8# × 5/8"	12 pcs



adjustable Leveler

Adjustable Shelf

Step 1



Adjust leveler if needed
to level case on uneven floor.