

PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

ITEM NO. / ARTICLE NO. / ARTICULO NO : S496-410

DESCRIPTION / DESCRIPCIÓN : DRESSER / COMMODE / TOCADOR

⚠ WARNING





Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



*This is a permanent label.
Do not remove!*



A

x8 JCBC Bolt M6 x 40MM *
x8 Boulon JCBC M6 x 40MM
x8 JCBC Perno M6 x 40MM



B

x8 Spring Washer M6 *
x8 Rondelle à ressort M6
x8 Arandela auto-bloqueante M6




C

x8 Flat Washer M6 *
x8 Rondelle Plate M6
x8 Arandela Plana M6




D

x1 Allen Key 4 x 65MM *
x1 Clé hexagonale 4 x 65MM
x1 Llave Allen 4 x 65MM




E

x4 Leg *
x4 Patte
x4 Pata



F

x1 Center Leg *
x1 Pattes centrales
x1 Patas centrales



G

x1 Tipping restraint
x1 Liste des pièces de quincaillerie antibasculement
x1 Abrazadera antivuelco

**Replaceable Part*

ASSEMBLY INSTRUCTIONS / NOTICE DE MONTAGE / INSTRUCCIONES DE MONTAJE

ITEM NO. / ARTICLE NO. / ARTICULO NO : S496-410

DESCRIPTION / DESCRIPCIÓN : DRESSER / COMMODE / TOCADOR

⚠ WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.





*This is a permanent label.
Do not remove!*



Level Me on Uneven Floor /
Me Nivelar sur un sol inégal /
Nivelarme en el suelo desigual





HARDWARE & LEGS (PACKED INSIDE DRAWER)
QUINCAILLERIE ET PIEDS (EMBALLÉS À L'INTÉRIEUR DU TIROIR)
HERRAJES Y PATAS (EMPAQUETADO DENTRO DEL CAJÓN)



AFFIX TO WALL
BEHIND DRESSER /
KENAFFIX AU MUR
DERRIÈRE LA
COMMODE /
KENAFFIX A LA
PARED DETRÁS DE
LA CÓMODA

Wall / Mur / Pared




**Replaceable Part*

REPLACEABLE PART / PARTIE REMPLAÇABLE / PARTE REEMPLAZABLE

ITEM NO. / ARTICLE NO. / ARTICULO NO : S496-410


DESCRIPTION / DESCRIPCIÓN : DRESSER / COMMUNE / TOCADOR



x4 RS496-410-KNOB *
Knob with Screw
Poignée + vis
Tirador + Tornillo




x4 RS496-410-PULL *
Pull with Screw
Tirer + vis
Tirer + Tornillo





x6 RS496-410-DG *
Drawer Glide
Glissière
Carril de deslizamiento




x4 RC-BR-NAIL *
Brown Plastic Nail
Clou en plastique
Clavo de plástico



x1 RS496-410-HWKIT *
Hardware Kit
Liste des pièces de quincaillerie
Lista del kit de materiales



x4 RS496-410-LEG *
Legs
Jambes
Piernas



x1 RS496-410-CELEG *
Center leg
Pattes centrales
Patas centrales

**Replaceable Part*