






A




x1 Table Top
x1 Dessus de la table
x1 Mesa parte superior

L




x1 Leg (Left)*
x1 Jambe (gauche)
x1 Pierna (izquierda)

R



x1 Leg (Right)*
x1 Jambe (droite)
x1 Pierna (derecha)

C



x1 Bottom shelf*
x1 Étagère inférieure
x1 Estante inferior

D



x4 Allen bolt Ø5/16"x38mm*
x4 Boulon Ø5/16"x38mm
x4 Perno Allen Ø5/16"x38mm

E



x6 Allen bolt Ø5/16"x58mm*
x6 Boulon Ø5/16"x58mm
x6 Perno Allen Ø5/16"x58mm

F



x10 Lock washer Ø5/16"*
x10 Rondelle de blocage Ø5/16"
x10 Arandela de Seguridad Ø5/16"

G



x10 Flat Washer Ø5/16"x19x1.5mm*
x10 Rondelle plate Ø5/16"x19x1.5mm
x10 Arandela plana Ø5/16"x19x1.5mm

H




x1 Allen Key 4mm*
x1 Clé hexagonale 4mm
x1 Llave Allen 4mm

I





x4 Dowel Ø8*30*
x4 Goujon Ø8*30
x4 Clavija Ø8*30


* Replaceable Part



* Replaceable Part




x1 RS762DJ-102-LEGL- Legs (Left)*
Jambes (gauche)
Piernas (izquierda)



x1 RS762DJ-102-LEGR- Legs (Right)*
Jambes (droite)
Piernas (derecha)




x4 RC-WH-NAIL-White Plastic Nail*
Clou en plastique
Clavo de plástico



x1 RS762DJ-102-OSHELF-Bottom shelf*
-Étagère inférieure
-Estante inferior



x2 RS762DJ-102 - BUTTON*
Button with Screw
Bouton et vis
Botón y Tornillo



x1 RS762DJ-102-HWKIT-Hardware Kit*
-Liste des pièces de quincaillerie
-Lista de materiales

* Replaceable Part